



Single-Phase Emergency Lighting Inverter (Outdoor) Harsh Environment Series Installation and Operation Manual

**Emergency Lighting Inverter (Outdoor)
Single-Phase, 2.1-17KW
Harsh Environment Lighting Inverter**

Sales

Email: sales@onlinepower.com

Sales: (800) 227-8899

Service

Email: Service@800pwrsrv.com

Service: (800) 797-7782

Due to continuous product improvement, this document is subject to change without prior notice

Document No.: 125-MAN, Rev. G

Notice of Rights

This document contains proprietary and confidential information of OnLine Power. No part of this manual may be reproduced, copied, translated or transmitted, in any form or by any means, without the prior written permission of the manufacturer.

In consideration of the receipt of this document, the recipient agrees not to copy any of its contents, nor to disclose them to or allow them to be used by any person not currently company employee or an employee of the recipient having a need to know, without the express written consent of the company, and further agrees to surrender this document to company when the reason for its receipt has terminated.

Notice of Liability

Information provided in this manual is intended to be accurate and reliable. However, manufacturer assumes no responsibility for its use, nor for any infringement of rights of third parties which may result from its use. THIS DOCUMENT IS PROVIDED "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL ABOVE COMPANY BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS DOCUMENT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

Harsh Outdoor Environment Installation and Operation Manual

Document No.: 125-MAN, Rev. G

April 17, 2025

Table of Contents

Table of Contents	3
Introduction.....	5
Scope and Audience.....	5
Safety and Warnings	5
Warranty Registration and Warranty Certificate Request	5
Service	6
Chapter 1. Safety	7
Chapter 2. Overview	11
2.1 Product Description	12
2.2 Product Main Features.....	14
Chapter 3. Hardware Overview	16
3.1 Key Components	17
3.2 Typical Functional Description	22
3.3 Theory of Operation	25
Chapter 4. Installation	27
4.1 Delivery Space Requirements.....	28
4.2 Site Considerations.....	32
4.3 Delivery and Handling.....	37
4.4 Storing the System	47
Chapter 5. Operation	48
5.1 Starting the Unit	49
Chapter 6. Maintenance	51
6.1 Safety Precautions.....	52
6.2 Preventative Maintenance	54
6.3 FRU Replacement	58
6.4 Calling for Service.....	64
6.5 Customer Service and Support	65

Chapter 7. Troubleshooting	66
7.1 Reset Instruction	67
7.2 Troubleshooting Guide and System Alarms	68
7.3 Using the LCD Display Panel	70
 APPENDIX A - Battery Connections	 73
 APPENDIX B - OPTIONS	 81
B.1 Internal Manual Bypass Switch (Make Before Break)	81
B.2 External Wrap-around Manual Bypass Switch (same Input and Output Voltage)	81
B.3 Audio Alarms with Silence Switch	84
B.4 Remote UPS Status Panel	84
B.5 Transient Voltage Surge-Suppressor (TVSS)	85
B.6 Offline Inverter Operation	85
B.7 Normally ON/OFF Output Aux. Circuit Breakers	85
B.8 Main Input CB Standard/Higher KAIC	85
B.9 Main Output CB Standard/Higher KAIC	86
B.10 Higher KAIC Normally ON/OFF Aux Output Circuit Breaker	86
B.11 Power Flow Mimic	86
B.12 Global Monitoring Systems (GMS)	87
B.12.1 Local Monitoring via PC with RS-232	89
B.12.2 Local Monitoring via PC with RS-485	89
B.12.3 RJ45 Ethernet connection	89
B.13 Simple Network Management Protocol	90
B.14 Heater Strip with Adjustable Thermostat	91
B.15 Battery String Monitoring (Wireless)	91
B.16 Battery (Individual) Monitoring (Wireless)	91
B.17 Form "C" N/O Contacts for Alarms	91
B.18 Dry Contact, N/O or N/C Contact with Isolated Common	91
B.19 Battery Breaker alarm	92
B.20 Intrusion switch	92
B.21 Air Conditioning (Heating & Cooling)	92
 APPENDIX C - specifications	 95
 Index	 99

Introduction

Congratulations on selecting one of the fine products from the leader in power-protection technology. Our wide product offering includes Uninterruptible Power Systems (UPS), power conditioners, automatic voltage regulators, and specialty transformers (e.g., computer-grade, medical-grade). Since 1972, the manufacturer has shipped many of these fine products to discerning customers around the world for use on sensitive equipment and critical applications.







The Single-Phase Lighting Inverter is a self-contained unit that provides backup power for fluorescent and incandescent lighting sources such as overhead fixtures and exit signs. If a brownout or power outage occurs, the inverter provides 90 minutes of lighting power to ensure a safe building evacuation. On line pulse-width modulation (PWM) handles the switchover from utility power to battery power automatically, without interruption or manual intervention. Convection cooling allows the inverter to operate virtually silently.

Scope and Audience

This guide is intended to be used as a reference for users responsible for installing, operating, and maintaining this equipment.

Safety and Warnings

This guide uses the following symbols to draw your attention to certain information.

Symbol	Meaning	Description
	Note	Notes emphasize or supplement important points of the main text.
	Tip	Tips provide helpful information, guidelines, or suggestions for performing tasks more effectively.
	Caution	Cautions indicate that failure to take a specified action could result in damage to the hardware.
	DANGER	The Danger symbol warns users of possible injury or death if instructions are not followed.
	Hazardous voltage	Hazardous voltage inside. Only authorized personnel may service this equipment.
	Electrostatic sensitive	Components are Electrostatic Discharge Susceptible (ESDS) Use a grounded ESD wrist strap.

Warranty Registration and Warranty Certificate Request

Web: www.800pwrsrv.com under download tab

Service

If you require assistance, fill out a Service Report Form at www.800pwrsrv.com, email us at service@800pwrsrv.com, or call our 24-hour toll free hot line (800-797-7782). Please have the unit's SERIAL NO. from the Start-Up **label** located on the top left corner of the front door for speed assistance.

Chapter 1. Safety

This chapter contains safety precautions to observe when operating or servicing electrical equipment. The symbols shown are used extensively throughout this manual. Always heed these precautions because they are essential to the safe operation and servicing of this product.



DANGER: This Equipment is intended to be permanently connected. Only factory-trained or authorized personnel should attempt to install or repair the unit or its batteries . Improper installation has proven to be the single most significant cause of start-up problems. High AC and DC electrical voltages are present throughout the unit(s) and incorrect installation or servicing could result in electrocution, fire, explosion, or equipment failure.



DANGER: Read this manual in its entirety before performing the installation, start-up, operation, or maintenance of the UPS unit or its batteries Failure to do so could result in electrocution, fire, explosion, or equipment failure.



DANGER: All power connections must be completed by a licensed electrician who is experienced in wiring this type of equipment. Wiring must be installed in accordance with all applicable national and local electrical codes. Improper wiring may cause damage to the equipment, injury or death of personnel. Verify that all high and low voltage input power circuits are de-energized and locked out before installing cables or making any electrical connections.



DANGER: Exercise extreme care when handling unit and batteries to avoid equipment damage or injury to personnel. Cabinets weigh several hundred pounds.



DANGER: Test lift and balance the cabinets before moving. Maintain minimum tilt from vertical at all times. The bottom structure will support the unit only if the forklift forks are completely underneath the unit.



DANGER: Observe all battery safety precautions during installation or service of the unit or batteries. Even with the battery circuit breaker in the off position, the danger of electrocution may still be present. The battery power to the unit must be locked and tagged "off" before performing any service or work on the unit. The battery manufacturer's safety information and material safety data sheet are located in a pocket attached to inside the front door of each unit. Failure to follow those instructions and the instruction listed above and elsewhere in this manual could result in an explosion, fire, equipment failure, or electrocution.



DANGER: All power to the unit must be locked and tagged "off" before performing any service or work on the unit. Failure to do so could result in electrocution.



DANGER: In case of fire involving electrical equipment, only carbon dioxide fire extinguishers, or those approved for use on electrical equipment, should be used. Use of water on fires involving live high voltage electrical circuits could present an electrocution hazard.



DANGER: Extreme caution is required when performing maintenance. Lethal voltages exist within the equipment during operation. Observe all warnings and cautions in this manual. Failure to comply may result in serious injury or death. Obtain qualified service for this equipment as instructed.



DANGER: Be constantly aware that the unit system contains high DC as well as AC voltages. With input power, off and the battery disconnected, high voltage at the filter capacitors and power circuits should discharge within 30 seconds. However, power circuit failures can occur, so you should always assume that high voltage might still exist after shutdown. Verify that power is off using AC and DC voltmeters before making contact.



DANGER: Some components within the cabinets are not connected to chassis ground. Any contact between floating circuits and the chassis is a lethal shock hazard.



DANGER: Internal battery strapping must be verified by the customer prior to moving this unit.

This unit contains non-spillable batteries. Keep the unit upright. Do not stack. Do not tip. Always follow the battery manufacturer's safety information, located in a pocket attached to the inside door of your unit, to prevent an accident that could result in injury or death.



DANGER: Lead-acid batteries contain hazardous materials. Batteries must be handled, transported, and recycled or discarded in accordance with federal, state, and local regulations. Because lead is a toxic substance, lead-acid batteries should be recycled rather than discarded.

Do not dispose of batteries in a fire, the batteries may explode.

Do not open or mutilate the batteries. Released electrolytes are harmful to the skin and eyes and may be toxic.

A battery can have a high short circuit current and present a risk of electrical shock. The following precautions should be observed when working on batteries:

- 1. Remove watches, rings, or other metal objects.**
- 2. Use tools with insulated handles.**
- 3. Wear rubber gloves and boots.**
- 4. Do not lay tools or metal parts on top of batteries.**
- 5. Disconnect charging source prior to connecting or disconnecting battery terminals.**
- 6. Determine whether battery is inadvertently grounded. If so, remove the source of the ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock will be reduced if such grounds are removed during installation and maintenance.**
- 7. Lead-acid batteries can present a risk of fire because they generate hydrogen gas. The following procedures should be followed:**
 - Do not smoke when near batteries.
 - Do not cause flame or spark in battery area.
- 8. Discharge static electricity from your body before touching batteries by first touching a grounded surface.**

Chapter 2. Overview

Topics:

- ⤴ Product Description
(page 12)
- ⤴ Product Main Features
(page 14)

This chapter provides an overview of the Single-Phase Lighting Inverter Harsh environment.

2.1 Product Description

The Harsh Environment Single-Phase Lighting Inverter is manufactured to provide critical power for lighting during a power outage. The Lighting Inverter meets or exceeds the life safety codes of UL924 and UL1778. These codes were established to allow emergency lighting inverters to provide critical power to the lighting circuits during a power failure.

If input power to the inverter is lost during a power outage, the system draws clean sine wave power automatically from its internal battery supply without any interruption. Power is provided for 90 minutes, sufficient time for safe and orderly evacuation from the facility.

An output transformer allows multiple output voltages as well as input voltages that are different from output voltages. Units are available from 3kva to 17kw with single-phase input or output of 120, 208, 240, 277 or 480 VAC.

The internal valve regulated lead-acid (VRLA), maintenance-free batteries provide 90 minutes of backup power. When input power is restored, the Lighting Inverter resumes normal operation automatically and begins recharging the batteries immediately.

An internal bypass circuit maintains power to the load in case an internal unit failure occurs. Comprehensive monitoring capabilities include a Liquid Crystal Display (LCD) panel and dry relay contacts for remote monitoring.

Refer to Table 2-1 for cabinet details.

Table 2-1. Harsh Environment Series Cabinet Dimensions

kVA/KW	Cabinet Size (Including Battery) (W x H x D in Inches)	Cabinet Type
3KVA ~ 5KW	39" x 73.5" x 20"	See Figure 4-1. 3KVA/KW To 5KVA/KW Cabinet
6.5kVA ~17 KW	51" x 77.5" x 33.5"	See Figure 4-2




Figure 2-1. Series Single-Phase Lighting Inverter Cabinets HE Series

2.2 Product Main Features

Item	Components	Function
1	Input Contactor K1	The input contactor is multifunctional. First, it provides connections for the input power to the unit. Secondly, the contactor disconnects the input line when an outage occurs so that there is no back feeding of power into the power line. Finally, the contactor allows for automatic unit operation upon a complete discharge of the batteries. No operator intervention is required when power to the unit is restored after a complete battery discharge.
2	Battery Charger	The battery charger maintains the batteries at full charge. After a battery discharge, the charger will automatically recharge the batteries upon restoration of input power. This circuit is on the Power Board.
3	Power Board Assembly with IGBTs	The Power Board is bolted onto the IGBT (Insulated Gate Bipolar Transistor) blocks that are mounted on a heat sink. The complete Heat Sink Assembly with IGBTs and Power Board is replaceable as a single part. This FRU (Field Replaceable Assembly) converts all the power, i.e. input AC power converted to DC bus, battery power boosted to DC bus, and finally DC bus power converted to output AC power using PWM technology for a smooth AC sine wave. In case of a catastrophic failure, the complete Heat Sink Assembly is easily replaceable using only a screwdriver. The Power Board also contains the housekeeping power supplies and drivers for the IGBTs. The entire assembly provides the landing place for all internal input, output, DC cables and metering devices for control and monitoring of the unit input and output currents.
4	Control Board	The microprocessor with unit specific firmware and control circuitry is located on the Control Board. The Control Board is mounted on the cabinet door and communicates with the Power Board (A2) via a ribbon cable. It monitors the input and output voltages and generates the command to close or open the input contactor and to sense and change the status of the bypass static switch. The Control Board sends data to the LCD panel located on the door where actual status and parameters are displayed. It additionally provides optional AS400, RS232, and RS485 output capabilities and supports various communication including SNMP options.
5	Output Static Switch	This SCR solid-state switch connects the output of the inverter (UPS) to the load. It is connected on the primary side of the optional output isolation transformer. This switch shuts off in case of a problem or failure within the unit and transfers the load directly to the utility input via the bypass static switch. It maintains its status opposite to that of bypass switch.

Item	Components	Function
6	LCD Display Panel	The LCD (L iquid C rystal D isplay) panel provides all the input, output, battery metering and alarm data, and UPS status for customer use on a constantly scrolling set of 2 default screens with continuous update.
7	Optional Output Isolation Transformer	The output isolation transformer provides isolation between the inverter and protected output. The power to the primary of this transformer is received from the unit and is transformed to required output voltage levels.
8	Optional Maintenance Bypass Switch	The MBS (M aintenance B ypass S witch) removes the critical load from the backup power and provides utility input directly to the load in case of a unit malfunction or during system maintenance.
9	Battery Bank	The battery bank consists of sealed, maintenance-free batteries. The batteries provide emergency power during power outages. The battery bank includes a breaker for over current protection and DC disconnect.

Chapter 3. Hardware Overview

Topics:

- ^ Key Components (page 17)
- ^ Typical Functional Description (page 19)
- ^ Theory of Operation (page 25)

This chapter provides an overview of the system hardware. It includes a description of the system's theory of operation.

3.1 Key Components

Figure 3-1. Key Components (3 to 5kVA/kW) typical and Figure 3-2 shows the key system components Typical location and describes them.




Figure 3-1. Key Components (3 to 5kVA/kW) typical




Figure 3-2 Key Components for all other units (typical)

Table 3-1. Key Components description

Callout	Component Name		Description
1	Heatsink FRU Assembly	Power board (A1)	The power board is bolted onto the Insulated Gate Bipolar Transistor (IGBT) blocks mounted on a heat sink. The complete heat sink assembly with IGBTs and power board is a single Field Replaceable Unit (FRU) that converts all the power: Input AC power converted to DC bus Battery power boosted to DC bus DC bus power converted to output AC power using PWM technology for a smooth AC sine wave If a catastrophic failure occurs, the heat sink assembly can be replaced using only a screwdriver. The power board also has the housekeeping power supplies and drivers for the IGBTs. The entire assembly provides the landing place for all internal input, output, DC cables, and metering devices for controlling and monitoring the unit input and output currents.
		Bypass static switch (PB2)	Bypass static switch is closed only upon inverter fault or output overload condition.
		Inverter static switch (PB1)	The SCR solid-state switch connects the output of the inverter (UPS) to the load. It is connected on the primary side of the optional output isolation transformer. If problem or failure occurs in the unit, this switch shuts off and transfers the load directly to the utility input via the bypass static switch. It maintains its status opposite to that of the bypass switch.
2	Input 2-Pole terminal block (TB1)		Customer Input power connection. See 4.3.6 (page 40)
3	Ground Lug (Input and Output)		2-barrel lug for Input and Output Ground. See 4.3.6 (page 40)
4	Output 2-Pole / 3-pole terminal block (TB1)		Customer output connection. See 4.3.6 (page 40)
5	Control board (A2)		The microprocessor with unit specific firmware and control circuitry is located on the Control Board. The Control Board is mounted on the cabinet door and communicates with the Power Board (A2) via a ribbon cable. It monitors the input and output voltages and generates the command to close or open the input contactor and to sense and change the status of the bypass static switch. The Control Board sends data to the LCD panel located on the door where actual status and parameters are displayed. It additionally provides optional AS400, RS232, and RS485 output capabilities and supports various communication including SNMP options.

Callout	Component Name	Description
6	LCD display panel	Provides continuously updated input, output, battery metering and alarm data, and UPS status for customer use on a constantly scrolling set of 2 default screens.
7	Terminal block for removing heat sink assembly (TB4)	5-position terminal block (TB4). This terminal block provides quick and easy removal of power assembly.
8	Fan transformer, Control power transformer (T2) Behind panel (Figure 3-1. Key Components (3 to 5kVA/kW) typical)	Provides 120 VAC to the fans, with taps to match unit output voltages.
9	Control transformer fuse (F1) Behind panel	Control transformer over current protection
10	Fan fuse (F2), behind panel	Fan overcurrent protection.
11	Fan(s)	Provides system cooling.
12	Output isolation transformer T1, as required	Provides isolation between the inverter and protected output. Power to the primary of this transformer is received from the unit and is transformed to the appropriate output voltage levels.
13	Inverter test switch (S2)	Push-button switch for testing the Lighting Inverter and its batteries for proper operation. When the unit is operating, pressing and holding in switch SW-2 transfers the system to battery operation. The system continues to run on batteries until the switch is released. When the switch is released, the system returns to normal operation so long as input power is present.
14	(Optional) Main Input breaker (CB3)	Provides input overcurrent protection (optional).
15	Battery breaker (CB1)	Provides overcurrent protection for battery bank.
16	(Optional) Main output breaker (CB2)	Provides output overcurrent protection (optional).
17	(Optional) Output Auxiliary Breakers	Normally ON/OFF Output Auxiliary Breakers (Optional)
18	(Optional) Gnd/Neu terminals	Gnd/Neu terminals for optional auxiliary output breakers.
19	(Optional) bypass switch	Optional: Removes the critical load from the backup power and provides utility input directly to the load in case the unit malfunctions or during system maintenance (optional). See section 3.2.5.
20	(Optional) TVSS (Transient Voltage Surge Suppressor)	This option is a no-fuse, fail-safe surge suppressor featuring a fail-safe self-protected design, visual indicator.
21	(Optional) Interfaces terminal blocks for customer connection (General location)	Options customer connections i.e. when 120Vac is required, form "C" contact terminals, each terminal is marked accordingly for proper connection refer to each option for connection details in each cabinet size.

Callout	Component Name	Description
22	Maintenance free lead acid battery(s)	Batteries are sealed, maintenance-free, self-regulated lead acid construction, to provide emergency power during power outages. Other battery options are available upon request.
23	(Optional) Heater Strip Thermostat Controller	Adjustable thermostat Control (Optional)
24	Manual holder	Manual is located inside the unit in the holder
25	Front door Air Filter	Air filters are installed to prevent dust and moisture entering the units

3.2 Typical Functional Description

shows the typical major blocks within the system and the sections following the figure describe them.




Figure 3-3. Major System Blocks

3.2.1 Inverter

The inverter accepts the available DC power from the rectifier or the battery banks and converts it to AC power for the critical load.

3.2.2 Battery Charger

The battery charger converts AC power into regulated DC power to recharge and maintain the charge on the battery bank. The charger is fully automatic, with a current-limiting feature that prevents battery damage in case of a charger malfunction.

The charger is sized so that the batteries are maintained at full charge, even when the input voltage is at the low line limit for indefinite periods of time.

3.2.3 Battery

The battery bank consists of (8, 10, 12, 16, or 20) 12-Volt batteries. These batteries provide the reserve energy to sustain the load when suitable AC input power is not present. The batteries are sealed, maintenance-free, valve-regulated lead acid (VRLA) construction.

3.2.4 Output Transformer

An output isolation transformer shall be utilized to provide specified multiple output voltages, while providing the following functions:

- **It provides excellent common mode and normal mode noise isolation of the load from the input or inverter power.**
- **It provides voltage transformation and tight regulation of the output voltage, while the system operates from its internal inverter.**
- **It can be used to provide a different voltage from the input source voltage.**

3.2.5 Internal Maintenance Bypass Switch, MBS Switch – Optional

Internal Manual Maintenance Bypass Switch is a (3) position “UPS”, “SBS” and “BYPASS” rotary switch, when set to “BYPASS” provides power directly from UPS main input feed to the load which ensures continuous power to critical load without interruption.



Caution: Do not leave the switch in the SBS position; otherwise, a loss of power to the critical load will occur when the inverter is de-energized.

3.2.6 Efficiency Optimizer Function: (OFF Line Inverter Mode)

When input power is available, the batteries are charged and AC output from the inverter supports the critical load via the inverter static switch. This is normal mode, during which the inverter static switch is closed, and the bypass static switch is opened. The bypass static switch is closed only during inverter faults or manual operation, in which case the critical load is supported by output power from the bypass static switch.

This is normal operation for true-double convention UPS. However, higher efficiency UPS operation can be achieved to reduce electricity costs by operating the unit as an “off-line inverter.” This scenario reverses the normal operating mode. Normally, the bypass static switch is closed as long as the input voltage and input frequency are within $\pm 10\%$ of the normal input voltage range and ± 3 Hz of the normal input frequency range, and the inverter static switch is opened. In off-line inverter mode, the inverter static switch is closed only if input power fails or when an out-of-voltage and frequency condition exists.

By eliminating the requirement for an output voltage regulation of $\pm 10\%$ (voltage window range) or $\pm 15\%$ (selectable) voltage window range:

- **System efficiency increases by 2% to 4% depending on the model**
- **Total power loss is reduced.**

- **The output AC voltage in the mode of operation follows proportionally to the input line voltage.**

3.3 Theory of Operation

The following section describes the system's theory of operation.

3.3.1 Standby Mode and Normal Mode

After power is applied to the system, the system enters standby mode and performs a self-test. During this period, the start subroutine checks for input voltage, and proper operation of the inverter and bypass SCRs. After the self-test completes successfully, the system enters normal mode.

During normal mode:

1. **Input contactor receives a closing signal that connects input power to the DC supply transformer.**
2. **The DC rectifier supplies the battery charger, control board, and the DC/AC inverter circuit.**
3. **The battery charger is activated, allowing the batteries to be charged continuously.**
4. **The on-line DC/AC inverter converts the DC voltage to a PWM waveform. This waveform is filtered and reconstructed to a desired AC output.**

3.3.2 Response to Input Power Failure

If the system controller senses a change in input frequency greater than ± 3 Hz or an out-of-range input voltage, it:

- **Considers the event as an input failure and opens the input contactor immediately, isolating the unit from the facility.**
- **Turns off the charger and makes the battery bank a DC supply source to the inverter circuit, maintaining an uninterrupted AC supply to the protected load.**
- **Issues a UPS ALARM message on the LCD display panel.**

When the facility power returns, stabilizes, and is in phase with the backup power, the system controller closes the input contactor and the system returns to normal mode. If the battery voltage drops below 16% of its nominal value and the facility power remains off, the system enters into alert mode.

3.3.3 UPS Alert

The system controller issues an **ALERT** message on the LCD display panel if any of the following conditions occurs:

- **Internal failure**
- **System overheats**
- **Battery bank undervoltage**

During an alert:

- **The system stops its backup operation.**
- **The inverter SCRs are switched OFF.**
- **Bypass SCRs are switched ON.**
- **A summary alarm 5V signal is sent to the hardwired interface.**

The system remains in this mode until power is cycled or the system is repaired.

3.3.4 UPS Alarm

The system controller issues a **UPS ALARM** message on the LCD display panel if any of the following conditions occurs:

- **Input power failure**
- **Output overload**

When the system is in alarm mode, inverter IGBTs remain on and an alarm signal may be sent to the signal interface. The system resets itself when the problem no longer exists.

3.3.5 Output Loads

The system is designed to power any fluorescent or incandescent HID lighting. However, certain types of loads exhibit an excessive inrush current when first turned on or at other times during operation.

As a result, the capacity of the system might need to be greater than the capacity that is estimated based on requirements shown on the system's nameplate. If you have questions about powering unusual loads from your system, contact your dealer or the factory.

Chapter 4. Installation

Topics:

- ^ Delivery Space Requirements (page 28)
- ^ Site Considerations (page 32)
- ^ Delivery and Handling (page 37)
- ^ Electrical Connections (page 40)
- ^ Storing the System (page 47)

This chapter describes how to install the system. It includes pre-installation information along with guidelines for storing the system for future use.

4.1 Delivery Space Requirements

Verify that the delivery area, the destination, and the path between them meet the standard delivery clearance and weight requirements of the system.

The delivery area must provide enough space and floor strength to support the packaged equipment cartons for the system. Doorways and hallways must provide enough clearance to move the equipment safely from the delivery area to the destination. Permanent obstructions such as pillars or narrow doorways can cause equipment damage. If necessary, plan for the removal of walls or doors.

Verify that all floors, stairs, and elevators you use when moving the system to its destination can support the weight and size of the equipment. Failure to do so could damage the equipment or your site.

The following figures show the dimensions of the system cabinets as well as key components used for cable access and mounting.




Figure 4-1. 3KVA/KW To 5KVA/KW Cabinet



Note: Use conduit plates only for drilling. (Do not discard the conduit plate)




Figure 4-2. 7.5KVA – 17KW Cabinet



Note: Use conduit plates only for drilling. (Do not discard the conduit plate)




Figure 4-3. Cabinet lifting brackets



Note: After final installation of the unit the 2 brackets can be turned upside down by using (7/32" Tamper-Resistant Hex) tool



Note: To prevent moisture entering the cabinet, all openings at the bottom must be weatherproof after installation.

Do not drill holes that will not be used on conduit plates.

4.2 Site Considerations

Planning the proper location and layout of the system prior to installing it is essential for successful operation. To ensure normal operation and to avoid unnecessary maintenance, plan your site configuration and prepare your site before installation, refer to Table 4.1 for facility recommendation.

The system is designed for indoor and outdoor installation and meets NEMA specifications for operating temperature, humidity, and utility voltage. The system enclosures are rugged and corrosion resistant.

The system is less than 6 square feet. All servicing is performed through the front of the unit; therefore, leave sufficient room in the front of the unit for service access.

The following precautions will help you plan an acceptable operating environment for the system:

Select a flat location that is clean, with no dust or exposure to direct sunlight or vibrations. The location should provide a sturdy, level surface that can support the system. Avoid locations with inclined floors.

The location should not be prone to variations in temperature and humidity or be close to strong magnetic fields or a device that generates electric noise.

The system should not be placed next to, on top of, or below any device that generates heat or will block the free flow of air through the system's ventilation slots.

The Lighting Inverter cabinets (Harsh Environment series) provide cable and conduit openings at the bottom of the cabinet.

Electrical equipment generates heat. Ambient air temperature might not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Ensure that the room in which the system will operate has adequate air circulation.



Caution: Always follow proper ESD-prevention procedures to avoid damage to equipment. Damage from static discharge can cause immediate or intermittent equipment failure.



Caution: For sites with **Generator** and **Automatic Transfer Switch (ATS)** in conjunction with the unit, make sure the ATS has an open transition with minimum 20 milli-seconds transfer time (gap) in **both directions**

4.2.1 Recommended Input / Output Protective Device Ratings, BTU/HR, & Floor Loading

Table 4.1

Unit Rating (KW)	Input Volt.	Unit Input Circuit Breaker (Amps) OPTIONAL	Recommended Facility Input Circuit Breaker Over Current Protection (AMP) (Note 1)	Output Volt.	Unit Output Circuit Breaker (Amps) OPTIONAL	Recommended Facility Output Circuit Breaker Over Current Protection (AMP)	Batt. Volt	Max. Batt. Disch AMP	*BTU/HR Double Conversion (Typical)	*BTU/HR Fast Transfer (Typical)	Unit Weight (including Batteries) lbs. (Approx.)	Floor Loading LB/SQFT	Cabinet Dimensions W x H x D Inches
2.1KW	120	50	Recommended Facility Input Circuit Breaker Should Be Equal to or Larger Than the Unit Input Circuit Breaker Ampacity	120	30	Recommended Facility Output Circuit Breaker Should Not Be Larger Than the Unit Output Circuit Breaker Ampacity	96	30	1037	Reduce 100 BTU/HR per KW	896	230	39 x 73.5 x 20
	208	30		208	20		96	30	1037		896	230	39 x 73.5 x 20
	240	25		240	15		96	30	1037		896	230	39 x 73.5 x 20
	277	25		277	15		96	30	1037		896	230	39 x 73.5 x 20
	480	15		480	15		96	30	1037		896	230	39 x 73.5 x 20
3KW	120	50		120	30		96	43	1037		1066	273	39 x 73.5 x 20
	208	30		208	20		96	43	1037		1066	273	39 x 73.5 x 20
	240	25		240	15		96	43	1037		1066	273	39 x 73.5 x 20
	277	25		277	15		96	43	1037		1066	273	39 x 73.5 x 20
	480	15		480	15		96	43	1037		1066	273	39 x 73.5 x 20
3.5KW	120	60		120	50		120	35	1146		1171	300	39 x 73.5 x 20
	208	50		208	30		120	35	1146		1171	300	39 x 73.5 x 20
	240	40		240	25		120	35	1146		1171	300	39 x 73.5 x 20
	277	30		277	25		120	35	1146		1171	300	39 x 73.5 x 20
	480	20		480	20		120	35	1146		1171	300	39 x 73.5 x 20
5KW	120	60		120	50		120	59	1419		1284	329	39 x 73.5 x 20
	208	50		208	30		120	59	1419		1284	329	39 x 73.5 x 20
	240	40		240	25		120	59	1419		1284	329	39 x 73.5 x 20
	277	30		277	25		120	59	1419		1284	329	39 x 73.5 x 20
	480	20		480	20		120	56	1419		1284	329	39 x 73.5 x 20
5.25KW	120	60		120	80		120	52.5	1620		1666	193	51 x 77.5 x 33.5
	208	60		208	50		120	52.5	1620		1666	193	51 x 77.5 x 33.5
	240	50		240	40		120	52.5	1620		1666	193	51 x 77.5 x 33.5
	277	50		277	35		120	52.5	1620		1666	193	51 x 77.5 x 33.5
	480	30		480	20		120	52.5	1620		1666	193	51 x 77.5 x 33.5
6KW	120	90		120	80		144	56	1965		1284	329	51 x 77.5 x 33.5
	208	50		208	50		144	56	1965		1284	329	51 x 77.5 x 33.5
	240	50		240	40		144	56	1965		1284	329	51 x 77.5 x 33.5
	277	40		277	30		144	56	1965		1284	329	51 x 77.5 x 33.5
	480	30		480	20		144	56	1965		1284	329	51 x 77.5 x 33.5

Unit Rating (KW)	Input Volt.	Unit Input Circuit Breaker (Amps) OPTIONAL	Recommended Facility Input Circuit Breaker Over Current Protection (AMP) (Note 1)	Output Volt.	Unit Output Circuit Breaker (Amps) OPTIONAL	Recommended Facility Output Circuit Breaker Over Current Protection (AMP)	Batt. Volt	Max. Batt. Disch AMP	*BTU/HR Double Conversion (Typical)	*BTU/HR Fast Transfer (Typical)	Unit Weight (including Batteries) lbs. (Approx.)	Floor Loading LB/SQFT	Cabinet Dimensions W x H x D Inches
7KW	120	90	Recommended Facility Input Circuit Breaker Should Be Equal to or Larger Than the Unit Input Circuit Breaker Ampacity	120	100	Recommended Facility Output Circuit Breaker Should Not Be Larger Than the Unit Output Circuit Breaker Ampacity	192	52	2800	Reduce 100 BTU/HR per KW	2042	236	51 x 77.5 x 33.5
	208	70		208	50		192	52	2800		2042	236	51 x 77.5 x 33.5
	240	60		240	50		192	52	2800		2042	236	51 x 77.5 x 33.5
	277	50		277	40		192	52	2800		2042	236	51 x 77.5 x 33.5
	480	40		480	30		192	52	2800		2042	236	51 x 77.5 x 33.5
7.5KW	120	100		120	100		120	88	2300		1074	236	51 x 77.5 x 33.5
	208	70		208	50		120	88	2300		1074	236	51 x 77.5 x 33.5
	240	60		240	50		120	88	2300		1074	236	51 x 77.5 x 33.5
	277	50		277	40		120	88	2300		1074	236	51 x 77.5 x 33.5
	480	40		480	30		120	88	2300		1074	236	51 x 77.5 x 33.5
8KW	120	100		120	100		192	56	2600		1464	375	51 x 77.5 x 33.5
	208	70		208	50		192	56	2600		1464	375	51 x 77.5 x 33.5
	240	60		240	50		192	56	2600		1464	375	51 x 77.5 x 33.5
	277	50		277	40		192	56	2600		1464	375	51 x 77.5 x 33.5
	480	40		480	30		192	56	2600		1464	375	51 x 77.5 x 33.5
8.75KW	120	150		120	100		192	64.5	2702		2572	298	51 x 77.5 x 33.5
	208	80		208	60		192	64.5	2702		2572	298	51 x 77.5 x 33.5
	240	60		240	60		192	64.5	2702		2572	298	51 x 77.5 x 33.5
	277	60		277	50		192	64.5	2702		2572	298	51 x 77.5 x 33.5
	480	40		480	30		192	64.5	2702		2572	298	51 x 77.5 x 33.5
10KW	120	150		120	100		192	74	3057		2870	332	51 x 77.5 x 33.5
	208	90		208	60		192	74	3057		2870	332	51 x 77.5 x 33.5
	240	70		240	60		192	74	3057		2870	332	51 x 77.5 x 33.5
	277	60		277	50		192	74	3057		2870	332	51 x 77.5 x 33.5
	480	40		480	35		192	74	3057		2870	332	51 x 77.5 x 33.5
10.5KW	120	150		120	150		240	76	3212		3132	363	51 x 77.5 x 33.5
	208	125		208	80		240	76	3212		3132	363	51 x 77.5 x 33.5
	240	125		240	60		240	76	3212		3132	363	51 x 77.5 x 33.5
	277	80		277	60		240	76	3212		3132	363	51 x 77.5 x 33.5
	480	40		480	35		240	76	3212		3132	363	51 x 77.5 x 33.5
12.5KW	120	175		120	125		192	92	3700		3777	437	51 x 77.5 x 33.5
	208	100		208	80		192	92	3700		3777	437	51 x 77.5 x 33.5
	240	90		240	70		192	92	3700		3777	437	51 x 77.5 x 33.5
	277	80		277	60		192	92	3700		3777	437	51 x 77.5 x 33.5
	480	45		480	35		192	92	3700		3777	437	51 x 77.5 x 33.5

Unit Rating (KW)	Input Volt.	Unit Input Circuit Breaker (Amps) OPTIONAL	Recommended Facility Input Circuit Breaker Over Current Protection (AMP) (Note 1)	Output Volt.	Unit Output Circuit Breaker (Amps) OPTIONAL	Recommended Facility Output Circuit Breaker Over Current Protection (AMP)	Batt. Volt	Max. Batt. Disch AMP	*BTU/HR Double Conversion (Typical)	*BTU/HR Fast Transfer (Typical)	Unit Weight (including Batteries) lbs. (Approx.)	Floor Loading LB/SQFT	Cabinet Dimensions W x H x D Inches
14.0KW	120	200	Recommended Facility Input Circuit Breaker Should Be Equal to or Larger Than the Unit Input Circuit Breaker Ampacity	120	200	Recommended Facility Output Circuit Breaker Should Not Be Larger Than the Unit Output Circuit Breaker Ampacity	240	103	5200	Reduce 100 BTU/HR per KW	4512	522	51 x 77.5 x 33.5
	208	125		208	125		240	103	5200		4512	522	51 x 77.5 x 33.5
	240	125		240	125		240	103	5200		4512	522	51 x 77.5 x 33.5
	277	100		277	100		240	103	5200		4512	522	51 x 77.5 x 33.5
	480	60		480	40		240	103	5200		4512	522	51 x 77.5 x 33.5
15.0KW	120	200		120	150		240	109	5000		4512	522	51 x 77.5 x 33.5
	208	125		208	90		240	109	5000		4512	522	51 x 77.5 x 33.5
	240	125		240	80		240	109	5000		4512	522	51 x 77.5 x 33.5
	277	100		277	70		240	109	5000		4512	522	51 x 77.5 x 33.5
	480	60		480	60		240	109	5000		4512	522	51 x 77.5 x 33.5
17.0KW	120	200		120	200		240	121	5400		4512	522	51 x 77.5 x 33.5
	208	125		208	125		240	121	5400		4512	522	51 x 77.5 x 33.5
	240	125		240	125		240	121	5400		4512	522	51 x 77.5 x 33.5
	277	100		277	100		240	121	5400		4512	522	51 x 77.5 x 33.5
	480	60		480	60		240	121	5400		4512	522	51 x 77.5 x 33.5



For all wire sizes consult local codes and NEC based on unit current requirements.

For Different Input / Output voltage units, add 100 BTU/HR per KW for Transformer.

Input / Output power connections (terminal blocks), accepting 14 AWG to 2/O AWG.

The external input circuit breaker protecting the unit must be a delayed trip type. this is due to magnetic inrush current drawn during application of AC power.

4.2.2 Operating Environment

The location you choose for installation should conform to the following conditions.

Table 4-2. Inverter Environmental Specifications

Inverter Environment	Description
Operating Temperature:	-20° to +50°C (-4° to 122°F) with optional heater Battery compartment to be kept at battery operating temperature
Altitude:	Up to 13000 ft (3,962 meters)
Relative Humidity:	0 to 95% RH, non-condensing
Audible Noise:	57 dBA, typical

Table 4-3. Battery Environmental Specifications

Battery Environment	Description
Ambient temperature:	20° to 25°C (68° to 77 °F)
Relative humidity:	0% to 95% (non-condensing)
Operating altitude:	Up to 13000 ft (3,962 meters)



Caution: Operating batteries outside of the specifications will shorten battery life significantly.

4.2.3 Floor Load Ratings

The floor space at the installation site must be strong enough to support the combined weight of the Lighting Inverter unit and all battery cabinets. To ensure adequate load-bearing capacity, plan for the maximum configuration.

4.3 Delivery and Handling

4.3.1 Inspecting the Shipment

The equipment included in your shipment consists of one Lighting Inverter cabinets. Batteries will typically ship separately unless specified otherwise. The contents are covered with protective wrapping and packaged in heavy-duty cardboard. Each item is labeled with the component name for easy identification.

When the equipment arrives, count the number of items delivered to ensure that you have the complete shipment. Inspect all protective wrapping or crates and any boxes for signs of rough handling or damage, such as punctures and crushed sides, preferably without moving the equipment. If the shipping container or equipment itself shows evidence of damage, record the damage on the receiving document before signing for receipt of the equipment. Damage claims should be filed directly with the carrier.


Thoroughly inspect each battery for any signs of damage. If there is any damage, reject the shipment and notify the manufacturer by email service@800pwrsrv.com. If possible, photograph the damage for future reference. As you unpack the pallet or container, check each battery box for damage on all sides, the top and bottom. If there is any sign of damage, photograph the damage if possible, and email service@800pwrsrv.com.

4.3.2 Off Loading the System

Because the system is designed for pad mounting, it is not accompanied by casters. At the user's discretion, a forklift can be used to off load the unit from the shipping pallet. Always be sure that the load capacity of the forklift is sufficient to support the weight of the unit and its battery cabinets.



DANGER: Exercise extreme care when handling the cabinets to avoid equipment damage or injury to personnel. Each cabinet weighs several hundred pounds. Test lift and balance the cabinets before moving. Maintain minimum tilt from vertical at all times. The bottom structure will support the unit only if the forklift forks are completely underneath the unit.



4.3.3 Climatization

Units that are shipped or stored at extreme temperatures require time to adjust to operating temperatures before startup. If the unit arrives in hot or cold weather, do not unpack it until it has been allowed to reach room temperature (one to two hours). Immediately exposing the unit to warm temperature can cause condensation to occur, which could damage the electronics. If you notice any condensation, allow the unit to stand unattended for one to two hours, and then unpack it.

4.3.4 Unpacking the Equipment

After checking the cartons for signs of damage, perform the following steps to unpack the equipment:

1. **Open all cartons.**
2. **Compare the items received to the packing list. If an item is missing or damaged, contact your place of purchase.**
3. **Remove all packing materials, envelopes, and boxes from the cartons. Please keep all packing materials and cartons in case you need to transport or ship the unit.**

In addition to the contents supplied with the unit, the user must supply a forklift to perform the installation.



Note: After unpacking and **before turn-on:**

Use plastic cover provided in the pouch on the front door to cover the unit during installation and while waiting for turn on, to prevent dust, construction debris and any other foreign object entering the unit.

Accumulation of dust and debris on all electronics will cause damage which will not be covered by warranty

4.3.5 Cabling and Mounting

1. **There are conduit entry plates provided at the bottom of the cabinet, drill conduit opening on the plates**



Note: Drill only for conduits that will be used.

2. **Anchor the cabinet to the mounting pad by removing the 4 corner mounting plates (see Figure 4-4 and Figure 4-5 for more detail).**
3. **Anchor the conduits to the conduit knockouts.**



Note: Use conduit plates only for drilling. (Do not discard the conduit plate)




Figure 4-4 3KVA/3KW systems




Figure 4-5 All other systems



Note: To prevent moisture entering the cabinet all openings at the bottom must be weatherproof after installation.

For all cable entries to the unit:

1. **Use conduit plates only for drilling. (Do not discard the conduit plate)**
2. **Ensure the conduit plate is bolted back after installation is completed**
3. **Ensure all conduit ends entering the cabinet at cable exit are sealed with foam sealant for weather proofing**

If you require more assistance email service@800pwrsvs.com

4.3.6 Electrical Connections

The following sections describe how to perform the electrical connections. In these sections, "TB" refers to terminal block. Before making electrical connections, observe the following:



DANGER: Verify that all customer-supplied wiring is de-energized before performing any electrical work. Failure to do so could result in electrocution, injury, or damage to equipment.



DANGER: Even when the unit is off, there are potentially dangerous voltages within the outdoor unit due to the batteries. Exercise extreme care when working within the system enclosure to avoid the possibility of electrocution, injury or damage to the equipment.




Figure 4-6 Input / Output Terminal Block Section Typical Arrangements




Figure 4-7 Single Output Voltage Connection with Optional Main Input/Output and Auxiliary Breakers (Typical)




Figure 4-8 Dual Output Voltage Connection with Optional Main Input/Output and Auxiliary Breakers (Typical)





Figure 4-9 Input and Output Connection Single Output Voltage (120V, 240V, 277V, 208V)

Table 4.4 Input and Output Connection Single Output Voltage

Input Connection			
Volt	TB1		Ground Lug
	1	2	Input
120	L1	N	GND (IN)
208	L1	L2	GND (IN)
240	L1	L2	GND (IN)
277	L1	N	GND (IN)
480	L1	L2	GND (IN)

Output Connection			
Volt	TB2		Ground Lug
	1	2	Output
120	L1	N	GND (OUT)
208	L1	L2	GND (OUT)
240	L1	L2	GND (OUT)
277	L1	N	GND (OUT)



4-10 Input and Output Connection Dual Output Voltage

Table 4.5 Input and Output Connection Dual Output Voltage

Input Connection			
Volt	TB1		Ground Lug
	1	2	Input
120V	L1	N	GND (IN)
208V	L1	L2	GND (IN)
240V	L1	L2	GND (IN)
277V	L1	N	GND (IN)
480V	L1	L2	GND (IN)

Output Connection				
Volt	TB2			Ground Lug
	1	2	3	Output
120V	L1	N		GND (OUT)
240V	L1		L2	
120V	L1	N		GND (OUT)
208V	L1		L2	
120V	L1	N		GND (OUT)
277V		N	L2	
277V	L1	N		GND (OUT)
480V	L1		L2	

4.3.6.1 Battery Connections

There are various battery configurations based on battery bus voltages. For reference purposes, see APPENDIX A - Battery Connections. For information about specific battery connections, refer to the battery connection diagram for each sales order.



Caution: Ensure that the DWG NO of the system matches the DWG NO on the nameplate. See the sample nameplate in


NAME	
<u>UPS CABINET</u>	
SERIAL NO.: _____ MODEL NO.: _____ RATING: _____ P.F.: _____ FREQUENCY: _____ INPUT VOLTAGE: _____ INPUT CURRENT: _____ OUTPUT VOLTAGE: _____ OUTPUT CURRENT: _____ BATTERY VOLTS: _____ BATTERY CURRENT: _____ BACK-UP TIME: _____ BATTERY QTY: _____ BATTERY P/N: _____ MFG DATE: _____ DWG NO: _____	
 US LISTED 183550	EMERGENCY LIGHTING AND POWER EQUIPMENT UL924/-A, CSA-C22.2.107.3-05 / UL1778 Ed.4. ALL VALUES ARE NOMINAL

Figure 4-11. Sample Nameplate

4.3.7 Optional Remote Signaling Connections

The Single-Phase Lighting Inverter includes optional dry contacts relay for remote signaling.

4.3.7.1 Form “C” N/O Contacts for Alarms

Refer to APPENDIX B- Figure 1 Interface terminal blocks

4.3.7.2 Dry Contact, N/O or N/C Contact with Isolated Common

Refer to APPENDIX B- Figure 1 for Interface terminal blocks

4.4 Storing the System

If you will not be using the system as soon as you receive it, keep it in its original packing material and store it in an indoor environment that meets the following conditions.

Specification	Description
Storage Temperature:	-20° to 70°C (-4° to 158°F)
Relative humidity:	0% to 95% (non-condensing)



Note: After unpacking and before turn-on:

Use plastic cover provided in the pouch on the front door to cover the unit during installation and while waiting for turn on, to prevent dust, construction debris and any other foreign object entering the unit.

Accumulation of dust and debris on all electronics will cause damage which will not be covered by warranty

4.4.1 Recharging Batteries During Storage

If the unit will be stored for three months or longer, visually inspect, and charge the batteries for 24 hours at regular, three-month intervals, refer to the battery label for battery voltage and use appropriate charger.

Chapter 5. Operation

Topics:

- ^ Starting the Unit (page 49)

This chapter describes how to operate the unit.

5.1 Starting the Unit

5.1.1 Pre-start up

The unit's batteries are shipped directly from manufacturer to ensure brand new batteries and allow an opportunity for the installing contractor to schedule their arrival when they are ready to commission the system. The battery cabinet and the interconnect cables are shipped with the electronics section of the inverter in a cardboard box located inside each battery cabinet.

Please be sure not to start up the unit without the assistance of a factory trained, authorize personal as failure to do so may damage the unit and void the unit warrantee.

To request a start-up: Either complete the form on line (6002-1545) and email it to service@800pwrsrv.com or fax a printed copy to Power Services at (323) 721-3929.



Caution: Ensure the unit is clean and free of dust and debris.

5.1.2 Preparation of Batteries

- a. Ensure proper number of batteries are delivered with your order. Verify quantity against battery drawing located in the inner door pouch.
- b. Place battery ID (Number) labels on each battery, refer to Battery Installation and Connection Instruction: Document No. 6005-329.
- c. Ensure batteries are charged within a 3 months period, after the initial receipt, follow the Service Log sheet (6002-2017-04) for battery maintenance scheduling to protect the warranty.
- d. Ensure that battery cables are properly torqued to the battery terminals. See battery drawing for torque values, found within the unit's door panel.
- e. Verify that the batteries are in a temperature-controlled environment.

5.1.3 Preparation of Electronics

- a. Ensure facility load is within full load rating of the electronics. Full load power rating of the unit can be found on name plate within the inner cabinet door.
- b. Make sure all input power, output power and DC terminal blocks are properly torqued.



Caution: All loads must be verified for short circuit test before connecting to the output of the unit.



Note: The pre start-up procedure described in this manual is a reference only to a start-up of the UPS for maintenance and shutdown.

5.1.4 Turning Off the Unit

There may be times when you need to turn off the unit, such as for planned maintenance.

To turn off the unit, perform this procedure in the following order:

1. Turn off the output breakers.
2. Turn off the battery breaker.
3. Turn off the input breaker.

5.1.5 Start-up procedure after shut-down or maintenance (Post Initial Start-Up)

Use the following procedure to start the unit after a planned maintenance shutdown or after a power outage. (Follow instruction on the label placed on the Maintenance Bypass Switch if the unit is in Maintenance Bypass Mode).

1. Apply input power.
2. With input power available, turn on the main input circuit breaker.
3. Wait until you hear the input contactor closing and fan running.
4. After the LCD display is lit and shows the following messages:

UPS NORMAL	@	##	KW
INPUT OK	@	CHRG	ON
BATTERY OK	@	DC	OK
ON INVERTER	@	OUT	OK

5. Close the battery circuit breaker.
6. Verify that all parameters on the LCD display panel matches the Nameplate.

OUTPUT:	_____ V	@	_____ KW
INPUT:	_____ V	@	_____ A
DC BUSS:	_____ V	@	_____ A
BATT:	_____ V	@	_____ A

7. Close the output circuit breaker.
8. Turn on the auxiliary output circuit breakers.

Chapter 6. Maintenance

Topics:

- ⤴ Safety Precautions (page 52)
- ⤴ Preventative Maintenance (page 54)
- ⤴ FRU Replacement (page 58)
- ⤴ Calling for Service (page 64)
- ⤴ Customer Service and Support (page 65)

This chapter describes how to maintain the system.

6.1 Safety Precautions

Observe the following safety precautions when performing maintenance on the unit.



DANGER: Read and understand this section thoroughly before performing any maintenance work on or around the UPS. Read the battery manufacturer's manual and material safety data sheets before working on or near the batteries. Only normal safety precautions are required when the UPS is operating with all cabinet doors closed. However, the UPS cabinets or Battery cabinets (if applies) must be kept free of standing puddles of water, excess moisture, or debris. **Debris can consist of excessive dust in and around the unit, as the cooling fans in the UPS will pull this dust into the unit.**



DANGER: Only factory trained, or authorized personnel should attempt to install or repair the UPS or its battery system. Improper installation has proven to be the single most significant cause of start-up problems. Service personnel should wear insulating shoes for isolation from direct contact with the floor (earth ground) and should make use of rubber mats when performing maintenance on any portion of the unit while it is under power. High AC and DC electrical voltages are present throughout the unit(s) and incorrect installation or servicing could result in electrocution, fire, explosion, or equipment failure.



DANGER: Special safety precautions and lockout tagout procedures are required for all operations involving the handling, installation, or maintenance of the UPS system and any associated batteries or battery cabinets (if applies). Failure to follow safety procedures could result in death, injury or damage to equipment.



DANGER: This equipment contains circuits that are energized with high voltages. Only test equipment designed for troubleshooting high voltages should be used, particularly for oscilloscopes and probes. Always check with an AC and DC voltmeter to ensure safety before initiating contact or using tools. even when the power is off, dangerously high potential voltages may exist at capacitor banks. Always observe battery precautions when operating near any batteries. Failure to observe these precautions could result in death or in injury or damage to equipment.



DANGER: Observe all battery safety precautions during installation or service of the UPS or batteries. Even with the battery circuit breaker in the off position, the danger of electrocution may still be present. The battery power to the unit must be locked and tagged "off" before performing any service or work on the unit. The battery manufacturer's safety information and material safety data sheet are located in a pocket attached to the inside of left door of each UPS. Failure to follow those instructions and the instruction listed above and elsewhere in this manual could result in an explosion, fire, equipment failure, or electrocution.



DANGER: Be constantly aware that the UPS system contains high DC as well as AC voltages. With input power, off and the battery disconnected, high voltage at the filter capacitors and power circuits should discharge within 30 seconds. However, power circuit failures can occur, so you should always assume that high voltage might still exist after shutdown. Verify that power is off using AC and DC voltmeters before making contact.

6.2 Preventative Maintenance

UPS operator maintenance consists of the basic tasks in this section. Other maintenance functions require factory Certified Service personnel.

6.2.1 Maintaining an Operator's Log

Careful record-keeping ensures proper maintenance of the unit and assists in the correction of any abnormal conditions.

The operator's log should contain the following information:

- **Date of system start-up**
- **Dates that battery maintenance was performed**
- **Dates that input, output, and battery status readings were checked, and the values displayed for these readings**
- **Dates and summaries of all communications with Service personnel**
- **A copy of Service Log Sheet is provided with each unit, the form 6002-2017-04 can also be requested by calling customer service support.**

6.2.2 Periodically Testing the UPS

The unit should be manually exercised on a periodic basis (for example, once every three months) to force the UPS unit to transfer to the battery and return to main power. This process activates self-diagnostic testing that can reveal conditions that require attention.

6.2.3 Maintaining the Batteries



DANGER: The battery circuit breaker operates at the rated battery voltages at all times. A tripped battery circuit breaker indicates a serious problem that may result in serious injury or damage to the equipment. Determine the cause and take appropriate action as necessary. For example, check for a short circuit in the battery. For guidance, email Power Services at service@800pwrsrc.com



DANGER: The battery electrolyte is a diluted sulfuric acid that is harmful to the skin and eyes. It is electrically conductive and corrosive. Wear full eye and hand protection along with protective clothing. If the electrolyte contacts the skin, wash it off immediately with water. If electrolyte contacts the eyes, flush thoroughly and immediately with water. Seek immediate medical attention. Spilled electrolyte should be washed down with a suitable acid neutralizing agent. One common practice is to use a solution of approximately one pound (450 grams) of bicarbonate of soda to approximately one gallon (4 liters) of water. The bicarbonate of soda solution should be applied to the spill until evidence of chemical reaction (foaming) has ceased. The resulting liquid should be flushed with water and the area dried.



DANGER: Do not dispose of a battery or batteries in a fire. The batteries may explode causing death or serious injury.



Caution: Do not substitute batteries from other manufacturers without the express approval of the manufacturer Customer Service personnel.



Caution: Lead-acid batteries contain hazardous materials and must be handled, transported, and recycled or scrapped in accordance with federal, state, and local regulations. Since lead is a toxic substance, lead-acid batteries should be recycled rather than scrapped.



Caution: A battery can present a risk of electrical short and high short circuit current. The following precautions should be observed when working on or around batteries:

1. **Remove watches, rings, or other metal objects.**
2. **Use tools with insulated handles.**
3. **Wear rubber gloves and boots.**
4. **Do not lay tools or metal parts on top of batteries.**
5. **Disconnect charging source prior to connecting or disconnecting battery terminals.**
6. **Determine whether battery is inadvertently grounded. If so, remove the source of the ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock will be reduced if such grounds are removed during installation and maintenance.**
7. **Lead-acid batteries can present a risk of fire because they generate hydrogen gas. The following procedures should be followed:**
 - Do not smoke when near batteries.
 - Do not cause flame or spark in battery area.
8. **Discharge static electricity from your body before touching batteries by first touching a grounded surface.**



DANGER: Do not ground battery positive or negative.



Caution: Lead-acid batteries can present a risk of fire because they generate hydrogen gas. The following safety procedures must be followed:

- **Do not smoke when near batteries.**
- **Do not cause flame or sparks in battery areas.**
- **Discharge static electricity from your body before touching batteries by first touching a grounded metal surface.**



Use of any non-Factory Tested/UL924 Certified batteries, including those with similar brand name and part number, will void the systems UL 924 Safety Certification Listing. Please call or e-mail Power Services for tested/certified replacement batteries.



Caution: The average annual ambient temperature of the batteries shall not exceed 77° F.



Caution: Battery Cell temperatures shall not exceed 92° F for more than 30 days annually.



Caution: Batteries are required to be installed and charged within 90 days of shipment.

6.2.4 Batteries

Although the individual batteries are sealed and require only minimal maintenance, they should be given a periodic inspection and electrical check. (Refer to schedule in log sheet provided inside front door pocket) to ensure years of trouble-free service. Tightness of battery terminal connections should be tested to recommended torque values. Battery Service Agreements are available through www.800pwrsvc.com. For information about battery environment specifications, see Table 4-3.

To qualify for battery-warranty replacement, you will need to show records of the battery maintenance history including battery numbers, battery voltages (individual cells), terminal torque measurements and dates of maintenance.

6.2.5 Power Connections

Check for corrosion and connection integrity. Visually inspect wiring for discolored or cracked insulation. Clean and/or re-torque as required.

All battery terminal connections must be tightened with the proper torque value set in accordance with the torque value on the Battery Connection Diagram provided with each system.

Use the correct torque tool to tighten the terminal bolts shown on the drawings on the battery cabinet. Use all hardware provided with the batteries.



Caution: Torque all connections in accordance with specified values provided. Failure to do so can create an unsafe condition or fire hazard.

6.2.6 Air Filters

Air filters must be replaced every 3 months or sooner depending on environmental conditions.

6.2.7 Weatherproof stripping or sealant

All weatherproof stripping or sealant requires periodic visual inspections and replacement ensure the units stays free of dust and moisture.

6.2.8 Preventative maintenance programs are available through the Customer Service representative.

6.2.9 Battery Terminals

Check for discoloration, corrosion, and connection integrity. Clean and tighten as necessary.

To access battery terminals:

- 1. Remove the top strapping material located at the lower front of the battery shelf.**
- 2. Pull the battery forward to access the battery connections.**
- 3. Disconnect the cables connected to the battery, and then use a protective boot or electrical tape to insulate the cables to prevent accidental shorts.**
- 4. Before replacing the battery connections, clean and re-torque the connection hardware.**

6.3 FRU Replacement

Some components can be replaced by qualified factory-trained service personnel only. These components are referred to as Field Replaceable Units (FRUs).

Refer to Table 6-1 for ordering the replacement parts from the factory. Provide the unit's Serial No. from the Start-Up **label** located on the top left corner of the front door.

North American users can call toll free: (800) PWR-SRVC. Replacement parts must be replaced by certified factory-trained service personnel only.



Electrostatic Sensitive: Circuit boards and IGBTs contain Electrostatic Discharge Susceptible (ESDS) components. Handle and package ESDS devices in accordance with JEDEC standard JESD625-A. Use a grounded ESD wrist strap when handling the devices and circuit boards. Always package components and circuit boards in static-dissipative plastic bags before transporting even if a device has failed. Failure to do so could result in further damage, complicating repair and failure analysis.

Table 6-1. Replacement Parts

Item	Description	Designator
1	Heat sink assembly	Power board (A1)
		Bypass static switch (PB2)
		Inverter static switch (PB1)
2	Power board	A1
3	Bypass static switch	PB1
4	Inverter static switch	PB2
5	Input/output/battery terminal block for customer use	TB1, TB2, TB3
6	Input choke	L1, L3
7	Output choke	L2
8	Dc choke	L4
9	The Frequency Noise Filter Capacitors for output Power	C1, C2, C3
10	Control board	A2 1625-288-XX (Standard) See Figure 6-3 Event log: Figure 6-4 Fast transfer: Figure 6-5
11	LCD display board	A5
12	Input contactor	K1
13	Terminal Block to remove heatsink assembly	TB4
14	Fan transformer	T3
15	Control power transformer	T2
16	Control transformer fuse	F1

Item	Description	Designator
17	Fan fuse	F2
18	Fan(s)	B1 thru B6
18	Optional output isolation transformer	T1
19	Input breaker	CB3
20	Battery breaker	CB1
21	Output breaker	CB2
22	Output distribution breaker	CB4 and up
23	Maintenance-free lead acid battery(s)	Battery 1 thru 20

6.3.1 Replacing the Heatsink Assembly

- To replace Heatsink Assembly:

1. Disconnect wires:

A4-P1	PB2-1	PB2-2	A3-P1	PB1-2	PB2-2
P4	P7	J1	Ribbon Cable	TB4-B (All wires)	P1 (when fast transfer option is used)

2. Remove heatsink (2) mounting screws and slide the assembly out

3. Use assembly handles to pull the assembly out



Caution: Do not use the cables as handle as this will cause damage

4. Install the replacement heatsink onto the tray and wire it to the unit by completing step 1-3 in reverse (see Figure 6-1 and Figure 6-2)

5. Verify all connections are tight and correct prior to starting up the unit.




Figure 6-1. Heatsink Assembly (units up to 5kw)




Figure 6-2. Heatsink Assembly (all others)

6.3.2 Replacing the Control Board (1625-288-XX) Standard

The control board is located on the inside right door for up to 5kw units and on the swing out panel on top front for all others.

Step	Tasks	Reference (picture, drawing, etc)
1.	Remove 4 PCBA Cover mounting screws and remove the Cover.	<p>Caution: This mounting screw creates a ground connection. A loose screw will create inadequate ground connection, causing problems.</p> <p>Optional</p> <p>Control PCBA (1625-288-XX)</p> <p>CAUTION RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER NO USER SERVICEABLE PARTS INSIDE. REFER SERVICE TO QUALIFIED SERVICE PERSONNEL</p> <p>PCBA Cover</p> <p>Standoff</p> <p>RIBBON CABLE</p>
2.	Look at the PCBA 1625-288-XX on the unit and take note of all the wires connected to the PCBA. Disconnect all the wire connectors from PCBA 1625-288-XX.	
3.	Hold the PCBA and remove the 4 standoffs. Remove the PCBA.	
4.	Install the replacement PCBA 1625-288-XX by completing steps 1-3 in reverse. Torque value 5 in-lbs.	

Connector	To PCBA	Standard
Ribbon cable	* J1	Yes
P7	J7	**Option
P3	J3	Yes
J12	P12	Yes
J2	J2	**Option
P11	J11	**Option
P5	J5	Yes
A2-J4	J4	Yes
P8	J8	**Option
P6	J6	**Option
P10	J10	**Option

*cable goes thru ferrite core on the back of the PCBA mounting panel.
**may not be required. Only required

Figure 6-3. Control Board (standard)

6.3.4 Replacing the (1625-405,406,407-XX) Fast Transfer option

This control board is located on the inside right door when fast transfer option is used

1 Phase Fast Transfer 1625-405-XX, 1625-406-XX, and 1625-407-XX Replacement																																		
Step	Tasks	Reference (picture, drawing, etc.)																																
1.	Disconnect all the connectors from PCBA 1625-405-XX, and 1625-406-XX.																																	
2.	Remove the 4 mounting screws and remove PCBA 1625-406-XX. Then remove the 4 standoffs and remove PCBA 1625-405-XX.																																	
3.	Install the replacement PCBA's 1625-405-XX and 1625-406-XX by completing step 1, and step 2 in reverse. Torque value 5 in-lbs.																																	
<table border="1"> <thead> <tr> <th>Connector</th> <th>To PCBA 1625-405</th> <th>To PCBA 1625-406</th> </tr> </thead> <tbody> <tr> <td>Overlay cable</td> <td>n/a</td> <td>J7</td> </tr> <tr> <td>A10J8</td> <td>n/a</td> <td>J8</td> </tr> <tr> <td>A10J4</td> <td>n/a</td> <td>J4</td> </tr> <tr> <td>A10J2</td> <td>n/a</td> <td>J2</td> </tr> <tr> <td>A10J1</td> <td>n/a</td> <td>J1</td> </tr> <tr> <td>A9J7</td> <td>J7</td> <td>n/a</td> </tr> <tr> <td>A9J6</td> <td>J6</td> <td>n/a</td> </tr> <tr> <td>A9J8</td> <td>J8</td> <td>n/a</td> </tr> <tr> <td>A9J2</td> <td>J2</td> <td>n/a</td> </tr> <tr> <td>A9J1</td> <td>J1</td> <td>n/a</td> </tr> </tbody> </table>			Connector	To PCBA 1625-405	To PCBA 1625-406	Overlay cable	n/a	J7	A10J8	n/a	J8	A10J4	n/a	J4	A10J2	n/a	J2	A10J1	n/a	J1	A9J7	J7	n/a	A9J6	J6	n/a	A9J8	J8	n/a	A9J2	J2	n/a	A9J1	J1
Connector	To PCBA 1625-405	To PCBA 1625-406																																
Overlay cable	n/a	J7																																
A10J8	n/a	J8																																
A10J4	n/a	J4																																
A10J2	n/a	J2																																
A10J1	n/a	J1																																
A9J7	J7	n/a																																
A9J6	J6	n/a																																
A9J8	J8	n/a																																
A9J2	J2	n/a																																
A9J1	J1	n/a																																
4.	Connect PCBA 1625-407-XX to PCBA 1625-406-XX.																																	

Figure 6-5. Fast Transfer option

6.3.5 All Other Parts

Verify that the cables are marked before disconnecting. Replace the defective part with the new part. Reconnect wiring the same way as it was disconnected.

6.4 Calling for Service

Call for service if you encounter any of the following conditions:

- **Repeated start-up attempts are unsuccessful.**
- **A UPS fault occurs that cannot be cleared.**
- **Normal operation of the critical load repeatedly causes an overload condition. This is not a UPS fault. A qualified person must analyze the total load connected to the UPS to prevent unit failure. Momentary overload conditions will be handled within the parameters of the UPS unit, but sustained overloads will cause the UPS Unit to fail.**
- **Any indicators or alarms operate abnormally or continuously.**
- **Any other abnormal function of the system occurs.**
- **If any abnormal battery condition is detected.**
- **When you are unsure of what action to take.**

If any of the above occurs:

Fill out a service request form by visiting www@800pwrsrv.com or email service@800pwrsrv.com



DANGER: Lethal voltages are present inside the equipment even when there appears to be no input power to the unit. Protect yourself from the risk of electrocution by referring service to qualified personnel only.

6.5 Customer Service and Support

Start-up, UPS maintenance, battery maintenance, and preventative maintenance programs are available through your Factory sales representative.

6.5.1 Start-Up Services

Various start-up services are available. Contact your sales representative or email us at service@800pwrsrv.com

6.5.2 Maintenance Agreements

Standard Full Service, 24/7 Full Service, and Extended On or OFF Site Maintenance agreements are available. Contact your sales representative or email service@800pwrsrv.com

6.5.3 Warranties

If you have any questions about the warranty on your UPS System or the batteries contact or email us at service@800pwrsrv.com or contact Customer Service and Support at 1-800-PWR-SRVC (800-797-7782).

Chapter 7. Troubleshooting

Topics:

- ⤴ Reset Instruction (page 67)
- ⤴ Troubleshooting Guide and System Alarms (page 68)
- ⤴ Using the LCD Display Panel (page 70)

This chapter describes typical LCD screens and some typical troubleshooting steps.

7.1 Reset Instruction

Due to facility and/or incoming power abnormalities, prior to initiating a service call please attempt a System "RESET" by following the Reset Instructions described below:

➤ **Instructions:**

- 1. Turn off all system output breakers.**
- 2. Turn off the systems battery breaker.**
- 3. Turn off MAIN FEED breaker that supplies input voltage to the unit.**
- 4. Check the systems LCD display to make sure it is completely off.**
- 5. When it has been verified to be completely off, turn the systems main feed input breaker back on.**
- 6. Wait for the contactor to close and wait for the LCD display to cycle two times.**
- 7. If the LCD display reads "UPS NORMAL", turn on the systems battery breaker.**
- 8. If the LCD display still reads "UPS NORMAL" after turning on the battery breaker, commence to turning on the system output breakers.**
- 9. Check to see if your output voltage is back to normal.**
- 10. If the LCD display still reads "UPS NORMAL" and all your output voltages are back to normal, your system has been fully reset. Close and lock the system doors**

7.2 Troubleshooting Guide and System Alarms

Case	Symptoms		Causes	Action
	Description	LCD Display		
1	Attempt to turn on and unit remains in BYPASS and LCD screen shows input OK	<div> UPS ALERT @ ## KW INPUT OK @ CHRG OFF BATTERY OK @ DC OK ON BYPASS @ OUT BAD </div>	Output is short-circuited	Replace Heatsink assembly. If problem still persists, go to next step
			Heatsink assembly has failed	Disconnect all loads then turn the unit back on. If it runs normally, request facility manager to check output loads for possible short. If problem still persists, go to next step
			Not Listed	email service@800pwrsrv.com for further action.
2	Attempt to turn on and unit remains in BYPASS_ and LCD screen shows input BAD	<div> UPS ALERT @ ## KW INPUT BAD @ CHRG OFF BATTERY OK @ DC OK ON BYPASS @ OUT BAD </div>	Connector P3 on control PCB gets loose	Check connector for proper seating. If problem still persists, go to next step
			Connector P3 has bad connection	Unplug P3, verify voltages are present across pin 1 & 2 and 3 & 4 for 3-phase. If no voltage is present, go to next step
			Control PCB failure	Replace control PCB. If problem still persists, go to next step
			Not listed	email service@800pwrsrv.com for further action.
3	Contactor keeps cycling or chattering	<div> UPS ALARM @ ## KW INPUT BAD @ CHRG ON BATTERY OK @ DC OK ON INVERTER @ OUT OK </div>	Fluctuation in input voltage and frequency	Verify input voltage to be within $\pm 10\%$ and frequency to be ± 3 Hz compared with nameplate spec. If these readings are OK, go to next step
			Contactor coil connector gets loose	Check contactor connections on control PCB P12. If problem still persists go to next step.
			Contactor coil failed	Unplug P12 on control PCB to verify coil resistance on the harness side. If open circuit is found, replace the contactor. If problem still persists, go to next step
			Control PCB failure	Replace Control PCB. If problem still persists, email service@800pwrsrv.com for further action.
			Heatsink assembly failure	Replace Heatsink assembly. If problem still persists, email service@800pwrsrv.com for further action.
			Not listed	Email service@800pwrsrv.com for further action.

Case	Symptoms		Causes	Action
	Description	LCD Display		
4	Unit went into FAILURE mode	<div> UPS ALERT @ ## KVA INPUT OK @ CHRG OFF BATTERY OV @ DC OV ON BYAPSS @ OUT BAD </div> Or <div> UPS ALERT @ ## KVA INPUT OK @ CHRG OFF BATTERY LOW @ DC UV ON BYAPSS @ OUT BAD </div>		Email service@800pwrsrv.com for further action.

7.3 Using the LCD Display Panel

All units have the screens in **Figure 7-2** and **Figure 7-3**. Units equipped with the optional output transformer also have the screen in **Figure 7-4**. All screens are updated continuously to provide you with up-to-the-minute status information.

When input power is applied to the unit, the LCD display panel lights up and displays the following message:



Figure 7-1. Message That Appears at Power-on

If your LCD display panel is not lit, the unit has a problem. Contact the factory service at via email service@800pwrsrv.com for further action.

7.3.1 Default Screen 1

Figure 7-2 shows the first default screen. **Table 7-1** describes the messages.

UPS NORMAL	@	##	KVA
INPUT OK	@	CHRG	ON
BATTERY OK	@	DC	OK
ON INVERTER	@	OUT	OK

Figure 7-2. Default Screen 1

Table 7-1. Description of Default Screen 1

Line	Message	Description
1	UPS NORMAL @ 15 KVA	15 KVA indicates the KVA rating. STAND BY or NORMAL = normal operating modes. STAND BY ALARM FAILURE = UPS alarm condition. FAILURE = unit failed or persistent alarm condition. Shut off the system and wait for the LCD to go dark, then restart the unit.
2	INPUT OK @ CHG ON	Shows one of the following conditions: INPUT OK = input within an acceptable range. INPUT BAD = input out of range. CHRG ON = charger on. CHRG OFF = charger is off. This occurs if the input capacitor is open or the system is in a failure mode (UPS ALARM).
3	BATTERY OK @ DC OK	Shows one of the following conditions. Note that the typical DC bus voltage should be higher than the battery voltage. BATTERY OK = battery voltage within an acceptable range. BATTERY OV = battery voltage high. This is normal when the battery is charging. BATTERY LOW = battery voltage low. Recharge battery. DC OK = DC bus voltage within an acceptable range. DC OV = DC bus voltage too high (UPS ALARM). DC UV = DC bus voltage too low (UPS ALARM).

7.3.2 Default Screen 2

Figure 7-3 shows the second default screen. Table 7-2 describes the messages.

OUTPUT: ___ V @ ___ KW
INPUT: ___ V @ ___ A
DC BUS: ___ V @ NA A
BATT: ___ V @ + ___ W


Figure 7-3. Default Screen 2

Table 7-2. Description of Default Screen 2

Line	Description
1	Shows one of the following: If an output transformer is not used, shows the output voltage and power in watts. If an output transformer (T1) is used, shows the primary voltage of the output transformer (T1) (typically 208 VAC).
2	Shows input volts and amps.
3	Shows the internal DC bus condition (for factory use).
4	Shows the battery voltage. (+) = current in Amps indicates charging Amps. (-) = discharging Amps.

7.3.3 Default Screen 3

If the optional output transformer is installed, the following screen shows the multiple output voltages. **Figure 7-4** shows the first default screen.



```
OUTPUT: 120V @  
OUTPUT: 208V @  
OUTPUT: 277V @  
OUTPUT: 480V @
```

Figure 7-4. Default Screen 3


APPENDIX A - BATTERY CONNECTIONS

This appendix shows typical battery connection diagrams. The figures are provided for electrical connection only and do not necessarily match the actual battery layout in your unit. The arrangement may be different from the figures. Each system is shipped with its own battery connection diagram located inside the front door pocket.




DANGER: The use of a physically damaged battery can cause a catastrophic system failure and can even result in a fire or explosion that could endanger life and property. Before accepting a battery shipment from the carrier, please read and follow these instructions:


- 1. Thoroughly inspect each battery for any signs of damage. If there is any damage, reject the shipment and notify the manufacturer. If possible, photograph the damage for future reference.**
- 2. As you unpack the pallet or container, check each battery box for damage on all sides, the top and bottom. If there is any sign of damage, photograph the damage if possible, and contact Power Service.**
- 3. Before you install each battery in the cabinet, remove it from its carton and thoroughly inspect it again on every side, the top and bottom for any signs of physical damage including, but not limited to, cracks, chips, leaks, bulges, and so forth.**
- 4. If a battery is dropped or makes hard contact with any object, inspect it again.**
- 5. Batteries are heavy, so exercise care when lifting them on to the shelves.**
- 6. Use of any non-Factory Tested/UL924 Certified batteries, including those with similar brand name and part number, will void the systems UL 924 Safety Certification Listing. Please call or e-mail Power Services for tested/certified replacement batteries.**
- 7. If at any time you have any questions regarding the condition of a battery, set it aside and notify the manufacturer at 800-PWR-SRVC (800-797-7782). Do not use a questionable battery under any circumstances, even temporarily.**




96-Volt Nominal DC Voltage,1 String of 8 Battery (Typical)




120-Volt Nominal DC Voltage, 1 String of 10 Battery (Typical)




120-Volt Nominal DC Voltage, 1 String of 10 Battery in 51" cabinet (Typical)




144-Volt Nominal DC Voltage, 1 String of 12 Battery (Typical)



192-Volt Nominal DC Voltage, 1 String of 16 Batteries (Typical)



192-Volt Nominal DC Voltage, 2 String of 16 Batteries in 51" cabinet (Typical)



240-Volt Nominal DC Voltage, 1 String of 20 Batteries (Typical)

APPENDIX B - OPTIONS

This appendix provides detailed information about the options available for the Single-Phase Lighting Inverter.

B.1 Internal Manual Bypass Switch (Make Before Break)

- To move from UPS mode to Bypass mode
 1. Turn off the battery breaker.
 2. Move the manual bypass switch to the BYPASS position.
- To move the Bypass mode to UPS mode
 1. Turn off the battery breaker.
 2. Move the manual bypass switch to the UPS position.
 3. Turn on the battery circuit breaker for normal operation.

B.2 External Wrap-around Manual Bypass Switch (same Input and Output Voltage)

The external maintenance bypass switch is mounted in a box that is field-installed and can be installed on adjacent wall. The single control simplifies the operation of the external manual bypass switch; however, operating instructions must be carefully observed before using the switch.

For ratings, wiring diagram, and enclosure dimensions, (see the figures on the following pages).

To access the operator control switch for the external manual bypass switch, open the cabinet front door. The manual bypass switch has three positions:

UPS – connects the critical load to the output of the inverter and establishes normal operation.


SBS – connects power to the critical load through the static bypass switch (for 0° phase angle synch).

BYPASS – connects power to the critical load through the bypass switch to bypass the inverter.

The BYPASS Switch is a 2 pole "MAKE BEFORE-BREAK". type. Contacts are Marked as "**UPS**", "**SBS**", and "**BYPASS**".

Use the wrap-around bypass switch with same input and output voltage only. For different input/output systems, use a switch with an external transformer. A wraparound bypass

switch can be used with systems **without any “built in secondary distribution circuit breaker” within the unit.**



Enclosure Dimensions

Amp	Voltage Class	Dimension (inches)				
		A	B	C	D MTG	E MTG
55 AMP	600V	14	16	6	12	16.75
110 AMP	600V	14	16	10	12	16.75
175 AMP	600V	20	20	12	18.5	18.5




Note: Do not leave the switch in “SBS” position



Note: This option is offered for same Input / Output voltage only.



Note: Wraparound bypass switch can't be used with units that have "Internal Secondary Distribution Circuit Breaker"



Maintenance Bypass Switch Wiring Diagram (Typical)

➤ **To install the maintenance bypass switch**

1. Always allow front access to the MBS box for maintenance and servicing.
2. Electrical codes require that the maintenance bypass switch box be installed with no less than 3 feet at the front of the cabinet.
3. Side and rear panels do not require service clearance; however, side vents must not be blocked.
4. Verify all power connections are tight.
5. Verify all control wire terminations are tight.
6. Verify all power wires and connections have proper spacing between exposed surfaces, phase-to-phase and phase-to ground.
7. Verify that all control wires are run in individual, separate steel conduit.



DANGER: All power connections must be completed by a licensed electrician who is experienced in wiring this type of equipment. Wiring must be installed in accordance with all applicable national and local electrical codes. Improper wiring may cause death, injury, explosion, fire, or damage to the equipment. Verify that all incoming high and low voltage power circuits are de-energized and locked out before installing cables or making any electrical connections.

B.3 Audio Alarms with Silence Switch


The audio alarms with silence switch provides an audible warning signal, acknowledge, and reset for Input Fail, On Bypass, Inverter On, Low Battery and Summary Alarm for any of the foregoing alarm conditions.

B.4 Remote UPS Status Panel

The remote UPS status panel is a console mount style box that can also be wall mounted and includes a 10-foot-long “DB” connector signal cable. An optional length cable up to 1000-feet long is also available.

The remote status panel has the following status LEDs.

- **INPUT OK** = input power is within acceptable range.
- **INVERTER ON** = inverter is ON.
- **ON BYPASS** = unit is in bypass mode.
- **ON BATT** = unit is operating from battery power.
- **LOW BATT** = battery voltage is low prior to shut down.
- **SUM ALARM** = unit is experiencing a critical alarm such as an over-temperature condition.
- **HORN** = audible warning for an alarm condition.
- **SILENCE SWITCH** = silences the audible warning.
- An **LED TEST** push-button allows you to test the LEDs.



Remote Status Panel

Refer to APPENDIX B- Figure 1 for Interface terminal blocks.

B.5 Transient Voltage Surge-Suppressor (TVSS)

The TVSS contains energy-absorbing components designed for specific line configurations. If protection components become damaged by absorbed transients, the device shows a reserve flag that indicates a need for replacement. The unit remains operational, but without surge protection.

B.6 Offline Inverter Operation

The offline inverter operation consists of a slow transfer unit and a fast transfer unit.

B.7 Normally ON/OFF Output Aux. Circuit Breakers

These 1-pole, 20A circuit breakers are designed to protect customer circuits and are offered as the following options:

- **Normally ON C.B. option**
- **Normally OFF C.B. option**
- **Normally OFF Delay C.B. option**

Standard output aux breakers are 10KAIC @ 120/240 volt, 6 KAIC @ 277 volts. Normally, ON/OFF.

B.8 Main Input CB Standard/Higher KAIC

This option consists of an input circuit breaker, standard, and higher KAIC.

B.9 Main Output CB Standard/Higher KAIC

This option consists of an output circuit breaker with higher KAIC.


B.10 Higher KAIC Normally ON/OFF Aux Output Circuit Breaker

Molded case type.

B.11 Power Flow Mimic

The power flow mimic option allows unit power status verification at-a-glance. Six LEDs indicate the following conditions:

- **Green** = Input OK or inverter is ON.
- **Yellow** = On battery, or on bypass.
- **Red** = Low battery or summary alarm.



Power Flow Mimic


B.12 Global Monitoring Systems (GMS)

1. Monitoring, Local On UPS – Event log

The control and monitoring PCBA collect up to one hundred event data and displays up to fifty of the most recent date-and time-stamped events. When the log is full, the oldest events are rolled off.


Keypad functions and resulting screens are presented below:

- LOG – press to display the event log. All stored events scroll continuously on display. Press this **key again to redisplay the main menu**.




Example of Logged Events

- FREEZE = press to freeze the default monitoring and alarms screen temporarily. Press this key again to return the display to the initial scrolling menu.



Example of Status Screen

- **INFO** = press to display system data on the screen. Press this key again to return to the default screen.




Example of System Info Screen

- **RESET and INFO** = press these keys at the same time to clear the display.

1. Monitoring, Local On UPS - Aux CBs Trip Monitor


Trip signals from the breakers are displayed on the circuit breaker trip screen. The circuit breaker is a part of default monitoring and alarm display that scrolls continuously when the unit is in operation.



B.12.1 Local Monitoring via PC with RS-232

The local monitoring via PC with RS-232 option requires a PC and LabView monitoring software. The software is provided on a disc that installs easily on any Windows operating system. An attached cable of a specified length plugs into a PC serial port and connector J6 on the Control Board located inside right door. LabView software must be configured to use COM port 1.

The LabView software translates data protocol coming to COM port from an active unit via the RS-232/RS-485 interface and displays the parameters and active alarms on a PC monitor. The following figure shows an example of a PC screen with measured parameters and actual unit status.



B.12.2 Local Monitoring via PC with RS-485

This option is similar to the local monitoring via PC with RS-232 option, except that an RS-485 cable is used instead of an RS-232 cable.

B.12.3 RJ45 Ethernet connection

B.13 Simple Network Management Protocol

This option consists an advanced SNMP NetAgent device.




Example of Advanced NetAgent Device

This option is available in the following offerings:

- Basic NetAgent SNMP with WI-FI HUB application
- Advance NetAgent SNMP with WI-FI HUB.
- Advance NetAgent SNMP with GPRS mobile modem.
- Advance NetAgent SNMP with dial-up modem

The following figures show examples of how this option can be used. In these figures, NetAgent mini and NetAgent II SNMP modules are installed inside the front door of the inverter cabinets.



B.14 Heater Strip with Adjustable Thermostat

The option provides flexibility of installing a heater with thermostat for adjusting temperature range to control harsh environment ambient temperature

B.15 Battery String Monitoring (Wireless)

The wireless battery monitoring system continuously monitors and communicates with the data collector to provide Real-time data. It analyzes and stores battery string voltage, current and (optional) cabinet temperature. For detail information request literature or visit our website.

B.16 Battery (Individual) Monitoring (Wireless)

The wireless battery monitoring system for individual battery block monitors each battery voltage, battery impedance and (optional) battery temperature sensor. For detail information request literature or visit our website.

B.17 Form “C” N/O Contacts for Alarms

The optional alarm relay board has a terminal strip TB for user connection to the individual alarm contacts. The Remote Contact Board includes isolated Form C contacts for the alarm signals in the following table.

Terminal Number	Signal	Description
TB-1	LOW BATTERY	N/O contact that closes when the unit is on battery operation and the batteries approach inadmissible discharge status.
TB-2	ON BYPASS	N/O contact that closes when the unit transfers the load to static by-pass.
TB-3	SUMMARY ALARM	N/O contact that closes when the unit has any one of the following alarm conditions. Internal Failure, System Overheat, Battery under-voltage.
TB-4	INVERTER ON	N/O contact that closes when inverter turns on
TB-5	INPUT FAIL	N/O contact that closes upon loss of input power.
TB-6	COMMON	Common Terminal
Refer to APPENDIX B- Figure 1 for Interface terminal blocks.		

B.18 Dry Contact, N/O or N/C Contact with Isolated Common

Terminal Number	Signal	Description
TB-18-1 (COM)	SUMMARY ALARM	When the unit has any one of the following alarm conditions. Internal Failure, System Overheat, Battery under-voltage.
TB-18-2 (N/O)		
TB-18-3 (N/C)		
TB-18-4 (COM)	ON BYPASS	When the unit transfers the load to static by-pass.
TB-18-5 (N/O)		
TB-18-6 (N/C)		
TB-18-7 (COM)	LOW BATTERY	When the unit is on battery operation and the batteries approach inadmissible discharge status.
TB-18-8 (N/O)		
TB-18-9 (N/C)		
TB-18-10 (COM)	INVERTER ON	Upon Inverter turned ON
TB-18-11 (N/O)		
TB-18-12 (N/C)		
TB-18-13 (COM)	ON BATTERY	Upon loss of input power.
TB-18-14 (N/O)		
TB-18-15 (N/C)		
TB18-16 to TB18-18	Spare	
Refer to APPENDIX B- Figure 1 for Interface terminal blocks.		

B.19 Battery Breaker alarm

It provides a signal when the battery breaker is in OFF position.

B.20 Intrusion Switch


Detects access into the interior of your system and provides an indication of the same.

Status monitoring with Dry Contacts Form "C" N/O or N/C. (see Appendix D Figure 2)

B.21 Air Conditioning (Heating & Cooling)

Maintains an internal unit temperature of 75°F, with a $\pm 5^\circ\text{F}$ tolerance, when external environmental temperatures range from -20°C to $+50^\circ\text{C}$.

Note: Air Conditioner option requires an additional 1.25kW for operation during a power outage.




APPENDIX B- Figure 1 (Communications and Alarm Signaling Interfaces)

APPENDIX C - SPECIFICATIONS

Typical Specifications (Input / Output Current)

1-Phase Input Current (0.7 PF RATED)																								
kVA/kW	3/2.1				5/3.5				7.5/5.25			10/7			12.5/8.75			15/10.5			20/14			
Voltage (vac)	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	120V	208V	240V	120V	208V	240V	120V	208V	240V	120V	208V	240V	
Max Current	29	17	15	13	44	25	22	19	36	30	26	74	40	35	57	49	43	68	59	51	89	77	66	
1-Phase Input Current (1.0 PF RATED)																								
kW	3.0				5.0				6.0				7.5		8.0		10.0		12.5					
Voltage (vac)	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	208V	240V	277V	208V	240V	277V	208V	240V	277V	208V	240V	277V
Max Current	40	23	20	17	60	35	30	26	69	43	36	31	51	41	36	48	42	36	64	56	48	79	69	59
kW	15.0				17.0																			
Voltage (vac)	208V	240V	277V		208V	240V	277V																	
Max Current	95	83	71		107	94	80																	
1-Phase Output Current (0.7 PF RATED)																								
kVA/kW	3/2.1				5/3.5				7.5/5.25			10/7		12.5/8.75		15/10.5		20/14						
Voltage (vac)	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V
Max Current	18	10	9	8	29	17	15	13	44	25	22	19	58	34	29	25	73	42	36	32	88	50	44	38
1-Phase Output Current (1.0 PF RATED)																								
kW	3.0				5.0				6.0			7.5		8.0		10.0		12.5						
Voltage (vac)	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V	120V	208V	240V	277V
Max Current	25	14	13	11	42	24	21	18	50	29	25	32	63	36	31	27	66	38	34	28	83	48	42	36
kW	15.0				17.0																			
Voltage (vac)	120V	208V	240V	277V	120V	208V	240V	277V																
Max Current	125	72	63	54	142	91	82	61																



APPENDIX D- Figure 2 (*Status monitoring with Dry Contacts*)

General Specification

Input

Voltage Regulation	+10% -15%
Frequency (Hz)	60 Hz \pm 3%
Power factor	0.98 to 1.0 (Typical)
Overcurrent protection	Electronic / Circuit Breaker (Optional)
Number of wires	2 Wires plus Ground
Power connection	Hard Wired (Terminal Block)

Output

Voltage (vac)	Single Phase, 120/208/240/277 VAC
Voltage Regulation	\pm 3% No Load to Full Load; \pm 3% High Line to Low Line
Frequency (Hz)	60 Hz \pm 0.5 Hz (When on Inverter)
Waveshape	Sine Wave
Harmonic distortion	<5% THD; <3% Single Harmonic
Crest factor	Up to 3 to 1
Power factor	0.65 Lagging or Leading to Unity
Overload	115% overload for 5 to 10 minutes, 125% for 30 seconds.
Protection	Electronic / Circuit Breaker
Noise rejection	-120 dB Common Mode ; -60 dB Normal Mode (with transformer Option)
Number of wires	2 Wires plus Ground for Single Voltage output, 3 Wires plus Ground for Dual Voltage output
Power connection	Hard Wired (Terminal Block)

Battery

Battery run time	90 minutes minimum									
Battery type	Sealed, Maintenance-Free, AGM, VRLA type									
Unit Rating (KW)	2.1 / 3	3.5 / 5	6	5.25 / 7.5	8	7 / 10	8.75 / 12.5	10.5 / 15	14 / 17	
Nominal dc voltage	96 VDC	120 VDC	144 VDC	120 VDC	192 VDC	192 VDC	192 VDC	240 VDC	240 VDC	
Overcurrent protection	Circuit Breaker									
Packaging	Batteries Housed in Same Enclosure and/or additional battery cabinet for other battery run time									
Monitoring and communications										
LCD Screen	Input Voltage; Battery Charger; UPS Output; On Battery; Low Battery; Summary Alarm									
Indicators	LCD Display Panel (Back lit)									
Relay interface	Dry Contacts for: Low Battery, On Bypass, Summary Alarm, Input Fail									
Contact rating	125 Volts (AC or DC) Maximum; 1.25 Amperes Maximum; 30 Watts / 50 VA Maximum									
Interface connection	Hard Wired (Terminal Block)									
Environmental										
Surge with standability	ANSI C62.41-1980 categories A & B									
Operating temperature	Meets NEMA requirements									
Operating relative humidity	0 to 95% non-condensing									
Altitude	-1000 to +13000 feet, derate 10% for each additional 1000 feet									
Cooling	Air cooled-forced air (fan)									
Physical										
Unit Rating	3KVA / 3KW		5KVA 5KW	6KW	7.5KVA 7.5KW	8KW	10KVA 10KW	12.5KVA 12.5KW	15KVA 15KW	20KVA 17KW
Dimensions (W x H x D in Inches)	39 x 73.5 x 20			51 x 77.5 x 33.5						
Construction	Painted Steel Enclosure, 3 point lockable front door, Full length hinged, for outdoor installation,									
Color	Neutral									
Accessibility	Front all Servicing is through the front no side or rear access required									
Cable entry	Bottom only									
Mounting	Four (4) mounting holes are provided for anchoring to floor, Hardware to be supplied by others									

Due to continuous product improvement, this document is subject to change without prior notice.

Index

A

Air Conditioner, 94
Alarms, 26
Alerts, 25
Audience, 5

B

Battery
 connections, 44
 maintaining, 53
 recharging, 46
 terminals, 56
Battery Monitoring, 91

C

Cabling, 37
Calling for service, 63
Climatization, 36
Controller board, replacing, 60
Customer service and support, 64

D

Delivery, 36
Delivery space requirements, 28

F

First-time power-up, 48
Floor load ratings, 35
FRU replacement, 57
Functional description, 22

H

Handling, 36
Heater Strip, 91

I

Intrusion Switch, 94
Inspecting the shipment, 36
Installation, 27

climatization, 36

L

LCD display panel, 69

M

Maintaining batteries, 53
Maintenance, 50
 preventative, 53
Maintenance agreements, 64
Modes, 25
Monitoring, Local On UPS - Aux
 CBs Trip Monitor, 88
Monitoring, Local On UPS – Event
 log, 86
Mounting, 37

N

Normal mode, 25

O

Offloading the system, 36
Operating environment, 35
Operation, 47
Operator's log, 53
Options
 details, 80
Output loads, 26
Output transformer
 messages on the LCD display
 panel, 70

P

Power connections, 55
Power Flow Mimic, 85
Preventative maintenance, 53
Product description, 12

R

Recharging batteries, 46
Replacing

 controller board, 60
Requirements
 delivery space, 28
Response to input power failure,
 25

S

Service, 6, 63
Shipment
 inspecting, 36
 unpacking, 37
Site considerations, 32
Standby mode, 25
Starting the unit
 after planned shutdown, 49
 first time, 48
Start-up services, 64
Storing the system, 46
System
 cabling and mounting, 37
 climatization, 36
 functional description, 22
 offloading, 36
 storing, 46
 theory of operation, 25
System blocks, 22

T

Testing the UPS, 53
Theory of operation, 25
Troubleshooting, 65
Turning off the unit, 49

U

Unpacking, 37
UPS
 alarm, 26
 alert, 25
UPS testing, 53

W

Warranties, 64
Warranty registration and
 warranty certificate request, 5