



NOTES:


All Dimensions are in Inches (Millimeters)

➡ Indicates Air Flow: Fans are on the top of the unit forces air out through the top.

Maintenance Service Clearance of 32" required in the front and recommended for the sides of the unit.



IG 3000	
System Installation Layout	
UP34085A-698	



IG 3000 (Uninterruptible Power System)

System Status
Panel



UP34084A-698